
Refrigerated Air Dryer

IDFB E Series

For use in North, Central & South America

Protect Pneumatic Equipment from Moisture!

An air dryer removes the vapor from the moist compressed air delivered by the compressor, and prevents it from causing the pneumatic equipment to fail.



0

0

-

an.

INDEX

1. Standard Products IDFB Series

Standard inlet air type Rated inlet air temperature: 100°F (37.8°C)



°F (2.8°C) 10 (17) 15 (25) 25 (43)	pressure dew 45°F (7.2°C) 11 (19) 16 (27) 26 (45)	point ^{Note)} 50°F (10°C) 12 (20) 17 (28)	Refrigerant	Rated inlet condition	Port size	Page
10 (17) 15 (25) 25 (43)	11 (19) 16 (27)	12 (20)			NPT 3/8	Page
15 (25) 25 (43)	16 (27)		-		NPT 3/8	
25 (43)		17 (28)				
	26 (45)				NPT 1/2	
	== ()	28 (47)	R134a			D 400 1- 400
41 (70)	43 (74)	45 (77)	(HFC)		NPT 3/4	P. 160 to 163
59 (100)	62 (106)	65 (110)				
71 (120)	80 (136)	86 (147)		100°F (37.8°C)	NPT 1	
13 (192)	155 (264)	177 (300)	R410A	100 psi (0.7 MPa)	R1 / NPT 1	P. 178 to 183
66 (282)	215 (366)	251 (426)	(HFC)		R1 1/2 / NPT 1 ¹ /2	P. 170 10 103
26 (384)	258 (438)	297 (504)	R407C			D 16440 166
00 (510)	353 (600)	406 (690)	(HFC)		INPT 2	P. 164 to 166
	9 (100) 1 (120) 3 (192) 66 (282) 26 (384)	9 (100) 62 (106) 1 (120) 80 (136) 13 (192) 155 (264) 36 (282) 215 (366) 26 (384) 258 (438)	9 (100) 62 (106) 65 (110) 1 (120) 80 (136) 86 (147) 13 (192) 155 (264) 177 (300) 36 (282) 215 (366) 251 (426) 26 (384) 258 (438) 297 (504)	1000 62 (106) 65 (110) 1 (120) 80 (136) 86 (147) 3 (192) 155 (264) 177 (300) 6 (282) 215 (366) 251 (426) 26 (384) 258 (438) 297 (504)	1000 62 (106) 65 (110) 1 (120) 80 (136) 86 (147) 3 (192) 155 (264) 177 (300) R410A (HFC) 26 (282) 215 (366) 251 (426) 26 (384) 258 (438) 297 (504)	1000 62 (106) 65 (110) 100°F (37.8°C) NPT 1 1 (120) 80 (136) 86 (147) 100°F (37.8°C) NPT 1 3 (192) 155 (264) 177 (300) R410A INPT 1 NPT 1 66 (282) 215 (366) 251 (426) R410A INPT 1 Int 1/2 / NPT 1 26 (384) 258 (438) 297 (504) R407C NPT 2

Note) Air flow capacity for each dew point is indicated.

2. Options

Optional specifications	Applicable model	Model (Suffix: Option symbol)	Page
Cool compressed air output	IDFB3E to 11E	IDFBDE-11-A	
Moderate pressure specification (up to 240 psi (1.6 MPa)) (Auto drain bowl: Metal bowl with level gauge)	IDFB6E to 15E	IDFB□E-□-K	
With heavy duty auto drain (Applicable to moderate pressure)	IDFB55E, 75E	IDFB□E-46-L	
With circuit breaker	IDFB4E to 75E	IDFB E- R	P. 167. 168
Power supply terminal block connection (Voltage symbol 11 only)	IDFB3E to 15E	IDFBDE-11-S	
With terminal block for power supply, run & alarm signal and remote operation	IDFB4E to 75E	IDFB□E-□-T	
Timer type solenoid valve with auto drain (Applicable to moderate pressure)	IDFB4E to 75E	IDFB□E-□-V	

3. Accessory (Option)

Description	Page	
Dust-protecting filter set	P. 169	

IDFB I E Series Model Selection

The corrected air flow capacity, which considers the user's operating conditions, is required for selecting the air dryer. Please select using the following procedures.

1	IDFB□E Selection Example					
1 Read the correction factor.	Condit	ion	Data symbol Correction factor Note			
_	Inlet air temperature	110°F (43°C)	A	0.82		
Obtain the correction factor A to D suitable for your operating condition using the table below.	Ambient temperature	105°F (40.5°C)	В	0.98		
condition using the table below.	Inlet air pressure	75 psi (0.53 MPa)	С	0.95		
	Air consumption	14 SCFM	—	—		
	Note) Values obtained from t	he table below.				
2 Calculate the corrected air flow capacity. Obtain the corrected air flow capacity from the following formula. Corrected air flow capacity = Air consumption ÷ (Correction factor A x B x C)	Corrected air flow capa	city = 14 SCFM ÷ (0 = 18 SCFM).82 x 0.98 x (0.95)		
3 Select the model. Select the model which air flow capacity exceeds the corrected air flow capacity using the specification table. (For air flow capacity, refer to the data D below.)	According to the corrected air flow capacity of 18 SCFM, the IDFB6E will be selected because its air flow capacity at 60 Hz is 25 SCFM.					
4 Option	Refer to pages 167, 168.					
5 Finalize the model number.	Refer to pages 160, 164	l				
6 Select accessories sold separately.	Refer to page 169.					

Data A: Inlet Air Temperature

Inle tempe	t air rature	Correction factor		
°F	°C	IDFB3E to 15E	IDFB55E, 75E	
90	32	1.31	1.08	
100	37.8	1.00	1.00	
110	43	0.82	0.83	
122	50	0.66	0.46	

Data B: Ambient Temperature

Ambient te	Correction factor	
77	25	1.24
90	32	1.09
95	35	1.04
100	37.8	1.00
104	40	0.98

Data C: Inlet Air Pressure

		Correction		
Inlet air	Inlet air pressure			
psi	MPa	factor		
75	0.53	0.95		
100	0.70	1.00		
110	0.76	1.04		
120	0.83	1.07		
125	0.86	1.09		
150	1.03	1.13		
175	1.21	1.18		
200	1.38	1.22		
232	1.60	1.24		

Data D: Air Flow Capacity

Model		Air flow capacity SCFM (m ³ /h (ANR))							
Widu	ei	IDFB3E	IDFB4E	IDFB6E	IDFB8E	IDFB11E	IDFB15E	IDFB55E	IDFB75E
0	37°F (2.8°C)	10 (17)	15 (25)	25 (43)	41 (70)	59 (100)	71 (120)	226 (384)	300 (510)
Outlet air pressure dew point	45°F (7.2°C)	11 (19)	16 (27)	26 (45)	43 (74)	62 (106)	80 (136)	258 (438)	353 (600)
	50°F (10°C)	12 (20)	17 (28)	28 (47)	45 (77)	65 (110)	86 (147)	297 (504)	406 (690)

Note1) In case of "Option A (Cool compressed air output)", the air flow capacity is different. Refer to page 167 for details. (IDFB3E to 11E)

Note2) The outlet air pressure dew point varies depending on the operating conditions.

Particularly when the outlet air pressure dew point is 37°F or 45°F, though this depends on the operating conditions, freeze protection functions may be activated, resulting in the dew point rising and becoming unstable.

If a stable low dew point is required, consider an IDG series membrane air dryer.





How to Order




Table of Options and Available Combinations (Size/Option)

Symbol Note 1)	Nil	A	К	R	S	т	v
Optional specifications Note 4) Size	None	Cool compressed air output	Moderate pressure specification ^{Note 2)} (Auto drain bowl: Metal case with level gauge)	With circuit breaker	Power supply terminal block connection Note 3)	With terminal block for run & alarm signal	Timer type solenoid valve with auto drain (Applicable to moderate pressure Note 2))
3	•	•	_	-	•	-	—
4	•	•	—	•	•	•	•
6	٠	•	•	٠	•	•	•
8	٠	•	•	٠	•	•	•
11	٠	•	•	•	•	•	•
15	•	—	•	•	•	•	•

Note 1) Enter alphabetically when multiple options are combined.

However, the following combination cannot be achieved. • Combination of S and T (Because S function is also included in T.)

Combination of S and T (Because S function is also included in 1.)
 Combination of K and V (Only one or the other may be attached.)

Note 2) The maximum operating pressure is 240 psi (1.6 MPa).

Note 3) Standard specification is the power cable with plug.

Note 4) Refer to pages 167 and 168 for further information on options.

Standard Specifications

	Model			Standar	d inlet air		
Specifications	Wioder	IDFB3E	IDFB4E	IDFB6E	IDFB8E	IDFB11E	IDFB15E
	101 002	101 042	Compre		101 0112	IDI DI CE	
nlet air temperature	F (°C)			41 to 122			
Inlet air pressure psi	(MPa)			22 (0.15) to 1	. ,		
ē - · · · · · · · · · · · · · · · · · ·	F (°C)		36 to 1	, ,	e humidity of 85%	or less	
	°F (2.8°C)	10 (17)	15 (25)	25 (43)	41 (70)	59 (100)	71 (120)
Air flow SCRI West 12 Outlet air pressure dew point 37 SCRI West 12 Outlet air pressure dew point 45 (m²h (ANR)) Outlet air pressure dew point 50 Operating pressure psi psi	°F (7.2°C)	11 (19)	16 (27)	26 (45)	43 (74)	62 (106)	80 (136)
S (m ³ /h (ANR)) Outlet air pressure dew point 50	"F (10°C)	12 (20)	17 (28)	28 (47)	45 (77)	65 (110)	86 (147)
Operating pressure psi	(MPa)			100	(0.7)		1
g Inlet air temperature °	F (°C)			100 (37.8)		
Ambient temperature °	100 (37.8)						
n Power supply voltage (frequ	iency)	Single-phase 115 VAC [voltage fluctuation ±10%] 60 Hz					
हु हैं Operating current Note 5) (A)		2.7	3.0	3.0	3.5	6.5	8.5
Power consumption Note 5)	(W)	240	260	260	310	550	800
Applicable circuit breaker capacity Notes (sensitivity current 30 mA)	^{te 6)} (A)	15					
Condenser		Forced air-cooled					
Refrigerant		R134a (HFC)					
Refrigerant charge	oz (g)	6.3 (180)	7.0 (200)	8.1 (230)	9.5 (270)	10.2 (290)	12.0 (340)
Symb	ool N	NPT 3/8 (female)	NPT 1/2 (female)		NPT 3/4 (female)		NPT 1 (female)
Thread symbol and size Symbol Nil		Rc 3/8 (female) With Rc conversion adapter	Rc 1/2 (female) With Rc conversion adapter	With	Rc 3/4 (female) Rc conversion ada	apter	Rc 1 (female) With Rc conversion adapter
Symb	ool N			3/8	inch		· ·
Drain tube O.D. Symbol Nil				10	mm		
Weight Ib	os (kg)	40 (18)	55 (25)	57 (26)	64 (29)	73 (33)	110 (50)
Compliant standards				UL,	CSA		•

Note 1) ANR is under the conditions of 68°F (20°C) at atmospheric pressure and relative humidity of 65%

Note 2) Air flow capacity for each outlet air pressure dew point is indicated.

Note 3) The operation range does not guarantee the use with normal air flow capacity.

Note 4) When operating conditions are different from the rated specifications, please select a model in accordance with the Model Selection (Page 159)

Note 5) These values are reference values under rated conditions, and are not guaranteed. Do not use these values for the thermal set values, etc.

Note 6) Product other than the option R is not equipped with an earth leakage breaker. Please purchase an appropriate earth leakage breaker separately.

Note 7) If this equipment suffers a short-term power outage (even if it is only momentary), it may require some time before normal operation resumes, and protective mechanisms may prevent normal operation even after the power supply has been restored.

Note 8) The maximum operating pressure is 240 psi (1.6 MPa) as standard, but it is possible to achieve 1.6 MPa when selecting Option K or Option V.

Replacement Parts

P	Model		IDFB4E	IDFB6E	IDFB8E	IDFB11E	IDFB15E	
Auto drain	Thread symbol N	, AD38	N-Z-D		AD48	N-Z-D		
replacement	Thread symbol Nil	AD:	AD38-D		AD48-D			
part no. Note 9)	Thread symbol N		8N-Z		AD48N-Z			
partito	Thread symbol Nil	AE	AD38		AD48			

Note 9) The part number for the auto drain (Bowl assembly) components without including the body part. Body part replacement is impossible

In addition, note that the auto drain part number differs depending on the serial number on the dryer specification label. For details, refer to page 170.

	Body
T.	Auto drain
E.	(Bowl assembly)


Symbol

air drver

Auto drain


Construction Principle (Circuit for Air/Refrigerant)

Humid, hot air coming into the air dryer will be cooled down by a cooler (heat exchanger). Water condensed at this time will be removed from the air by a drain separator (auto drain) and drained out automatically. Air separated from the water will be heated by a re-heater (heat exchanger) to obtain the dried air, which goes through to the outlet side



IDFB E Series


Dimensions



IDFB4E to IDFB11E

[226] [410] [473] [67] [125] [304] [33] [73] [31] [36] [154] [21] [330] [15]

[485] [568]



SMC

[300]

[355]

IDFB11E

Refrigerated Air Dryer IDFB E Series


IDFB15E I в D A Q Ventilation air outlet Compressed air outlet Illuminated switch Compressed O Ħ 100 air inlet Evaporation thermometer G ų, h ⊕ Drain separator Ventilation air outlet Ventilation Ventilation υ .jĻ. direction direction ji. \Box \Box السبالسيا لسبالسيا لسبا ш Drain tube (O.D.: ø0.4 [ø10 mm], H Length: 31.5 [0.8 m]) ol <u>6</u>0 'n. 1 4 н ĸ 4 x ø0.5 [4 x ø13 mm] L Ν Μ Power cable with plug (Length: 110 [2.8 m]) Dimensions Unit: inch [mm] С D G н Ν Q Model Port size A в Е F J κ L Μ 11.8 23.7 22.8 1.6 2.1 16.6 3.4 10.2 1.7 0.6 10.6 4.0 15.0 0.6 IDFB15E 1 [300] [603] [578] [41] [54] [396] [87] [258] [43] [15] [270] [101] [380] [16]

Dimensions

Refrigerant R407C (HFC) Standard Inlet Air **IDFB E Series** 55E, 75E

(Max. inlet air temperature: 122°F [50°C], Max. ambient temperature: 104°F [40°C])

The IDFB22E/37E has been discontinued.



Note 1) Enter alphabetically when multiple options are combined.

However, the following combination cannot be achieved.

· Combination of L and V (All of them are auto drain and only one or the other may be attached.)

Note 2) The maximum operating pressure is 240 psi (1.6 MPa).

Note 3) Refer to pages 167 and 168 for further information on options.

Standard Specifications

	~	Model	Standard	l inlet air	
Spe	ecifications		IDFB55E	IDFB75E	
			Compressed air		
es S	Inlet air temperature	°F (°C)	41 to 122 (5 to 50)		
atin	Inlet air pressure	psi (MPa)	22 (0.15) to 150 (1.0) Note 8)		
Operating Note 3) ranges	Ambient temperature	,	36 to 104 (2 to 40) Relativ		
	Air flow Outlet air pressure dew	. , ,	226 (384)	300 (510)	
S Not	capacity SCFM Note 1, 2) Outlet air pressure dew	point 45°F (7.2°C)	258 (438)	353 (600)	
tion	(m ³ /h (ANR)) Outlet air pressure dew	r point 50°F (10°C)	297 (504)	406 (690)	
Rated conditions Note 4)	Operating pressure	psi (MPa)	100		
o co	Inlet air temperature	°F (°C)	100 (37.8)		
Rate	Ambient temperature	e °F (°C)	100 (37.8)		
tics	g Power supply voltage (frequency)		Three-phase 460 VAC [voltage fluctuation ±10%] 60 Hz		
rica	Operating current Not	te 5) (A)	3.8		
act	Power consumption	Note 5) (W)	2400		
Electrical characteristics	Applicable circuit breaker cap (sensitivity current 3		10		
Co	ndenser		Forced a	ir-cooled	
Ret	frigerant		R407C	(HFC)	
Ret	frigerant charge	oz (g)	15.2 (430)	20.8 (590)	
The	read symbol and size	Symbol N	NPT 2 (male)		
	caa symbol and size	Symbol Nil	R 2 (r	nale)	
Dra	in tube O.D.	Symbol N	3/8 i	nch	
	an (abc 0.5.	Symbol Nil	10 1	nm	
We	ight	lbs (kg)	258 (117)	271 (123)	
Co	mpliant standards		Compliant standards UL, CSA		

Note 1) ANR is under the conditions of 68°F (20°C) at atmospheric pressure and relative humidity of 65%

Note 2) Air flow capacity for each outlet air pressure dew point is indicated.

Note 3) The operation range does not guarantee the use with normal air flow capacity.

Note 4) When operating conditions are different from the rated specifications, please select a model in accordance with the Model Selection (Page 159)

Note 5) These values are reference values under rated conditions, and are not guaranteed. Do not use these values for the thermal set values, etc.

Note 6) Product other than the option R is not equipped with an earth leakage breaker. Please purchase an appropriate earth leakage breaker separately.

Note 7) If this equipment suffers a short-term power outage (even if it is only momentary), it may require some time before normal operation resumes, and protective mechanisms may prevent normal operation even after the power supply has been restored.

Note 8) The maximum operating pressure is 240 psi (1.6 MPa) as standard, but it is possible to achieve 1.6 MPa when selecting Option K or Option V.

Replacement Parts

N	lodel		IDFB55E	IDFB75E	
Auto droin	Thread symbol N	New	AD48N-Z-D		
Auto drain replacement	Thread symbol Nil	New	AD4	8-D	
part no. Note 8)	Thread symbol N	Desuisus	AD48N-Z		
part no.	Thread symbol Nil Previous	Previous	AD	48	

Note 8) The part number for the auto drain (Bowl assembly) components without including the body part. Body part replacement is impossible. In addition, note that the auto drain part number differs depending on the serial number on the dryer specification label. For details, refer to page 170.




Construction Principle (Circuit for Air/Refrigerant)

Humid, hot air coming into the air dryer will be cooled down by a cooler re-heater (heat exchanger). Water condensed at this time will be removed from the air by a drain separator (auto drain) and drained out automatically. Air separated from the water will be heated by a cooler re-heater (heat exchanger) to obtain the dried air, which goes through to the outlet side.


IDFB55E, IDFB75E

ÌSMC



IDFB E Series

Dimensions



IDFB Series **Optional Specifications 1**

Refer to "How to Order" on pages 160 and 164 for optional models.

Body

Auto drain (Bowl assembly)

Option symbo

IDFB3E to 11E Cool compressed air output

There is no heating of cooled, dehumidified air as it leaves the air dryer. The air flow capacity with this option is smaller than that of the standard dryer. (The external dimensions are identical with the standard product.) Note) Perform thermal insulation treatment for pipings and equipment installed after the dryer to prevent the formation of condensation.

Air Flow Capacity

Model	IDFB3E	IDFB4E	IDFB6E	IDFB8E	IDFB11E
Air flow capacity (ANR)	5 SCFM	13 SCFM	17 SCFM	19 SCFM	23 SCFM
	(8 m ³ /h)	(23 m ³ /h)	(29 m ³ /h)	(32 m ³ /h)	(39 m ³ /h)

Conditions: Inlet air pressure: 100 psi (0.7 MPa), Inlet air temperature: 100°F (37.8°C). Outlet air temperature: 50°F (10°C), Ambient temperature: 100°F (37.8°C)



Moderate pressure specification Auto drain bowl: IDFB6E to 15E Metal bowl with level gauge

The auto drain is changed from the standard one to one with a moderate pressure specification.

A metal bowl with a level gauge which can confirm the water level is used for the auto drain.

Specifications

- 1. Maximum operating pressure: 240 psi (1.6 MPa)
- 2. Dimensions --- same as standard products

Replacement Parts

Model	Auto drain assembly part no. Note)	Note				
IDFB6E to 15E-11N	IDF-S1927	The AD48N-8Z-A-X2112 auto drain (bowl assembly) excluding the body, insulator, and One-touch fitting are included.				
IDFB6E to 15E-11	IDF-S1926	The AD48-8-A-X2112 auto drain (bowl assembly) excluding the body, insulator, and One-touch fitting are included.				

Note) A new line of auto drain models was released in March 2019. The previous models and the new models do not have mounting interchangeability. Refer to page 170 for details.



More thorough drain discharge can be achieved by replacing the float type auto drain (used with standard equipment) with a heavy duty auto drain (ADH4000-04)

(The external dimensions are identical with the standard product.)

Maximum operating pressure: 240 psi (1.6 MPa)

Replacement Parts


Model	Replacement part no. (Description)	Configuration
IDFB55E, 75E	ADH-E400 (Exhaust mechanism replacement kit)	Exhaust mechanism replacement kit Housing (a mounted unit is used)

Option symbol With circuit breaker

IDFB4E to 75E


A circuit breaker with cover is attached to the side of the air dryer. This saves additional electrical wiring at the time of installation.

IDFB4E to 15E



Dimensions Unit: inch [m					
Model	Α	В	С	D	E
IDFB4E, 6E, 8E, 11E	1.3 [32]	9.0 [230]	3.8 [97]	1.3 [34]	0.6 [15]
IDFB15E	1.7 [43]	10.2 [258]	4.0 [102]	3.2 [82]	_

IDFB55E/75E



Dimensions Unit: inch [mr						inch [mm]
Model	Α	В	С	D	E	F
IDFB55E, 75E	5.7 [145]	2.2 [56]	3.8 [96]	2.4 [60]	2 [50]	1.4 [36]

Breaker Capacity and Sensitivity Current

Model	Breaker capacity	Sensitivity current
IDFB4E to 15E	10 A	30 mA
IDFB55E, 75E	10 A	30 mA

IDFB Series **Optional Specifications 2**

Refer to "How to Order" on pages 160 and 164 for optional models.




Option symbol Power supply terminal

IDFB3E-11 to 15E-11


The option allows the connection of a power cable to a terminal block. 460 V specification is equipped as standard.

IDFB3E Terminal block


block connection



IDFB4E to 11E Terminal block



IDFB15E Terminal block



(Wire diameter ø0.4 [ø9 to 11 mm])




With terminal block for power supply, run & alarm signal and remote operation

In addition to the terminals for the power supply, terminals for the operating signal and the error signal are also available. (No-voltage contact) Also, in case of remote control, operate it from the power supply side while the air dryer switch remains ON.

IDFB4E to 75E


Contact capacity: 230 VAC, 4 A 24 VDC, 5 A for operating and error signals. Minimum current value: 20 V, 5 mA (AC/DC) for operating and error signals. Note) Please be sure to confirm the electric circuits with the drawings or instruction manual before using the output signal.

IDFB4E to 15E



Dimensions Unit: inch [mm						
Model	Α	В	С	D		
IDFB4E, 6E, 8E, 11E	1.3	9.0	2.6	7.0		
	[32]	[230]	[67]	[179]		
IDFB15E	1.7	10.2	3.0	6.2		
	[43]	[258]	[77]	[158]		

IDFB55E/75E



Imoneione

Dimensions Unit: inch [mm						
Model	Α	В	С	D		
IDFB55E, 75E	2 [50]	1.4 [36]	10.6 [270]	3.2 [81]		

Option symbol

Timer type solenoid valve with auto drain (Applicable to moderate pressure

IDFB4E to 75E

Drainage is discharged by controlling a solenoid valve with a timer. A strainer for solenoid valve protection and stop valve are also included. (The external dimensions are identical with the standard product.)

Maximum operating pressure: 240 psi (1.6 MPa)

* The timer type solenoid valve actuates once (for 0.5 seconds) every 30 seconds.

Replacement Parts

Model	Part no.	Note
IDFB4E to 15E-11	IDF-S0199	115 VAC
IDFB55E, 75E-46	IDF-S0302	230 VAC



IDFB□E Series Accessory (Option)

	Features	Specifications	Applicable dryer
Dust-protecting filter set	Prevents a decline in the performance of the air dryer, even in a dusty atmosphere.	Max. ambient temperature 104°F (40°C)	IDFB3E to 75E


How to Order

Dust-protecting filter set

I	DF –	-FL 209					
Applicable dryer							
	Symbol	Applicable dryer					
	209	IDFB3E					
	203	IDFB4E IDFB6E					
	204	IDFB8E					
	205	IDFB11E					
	206	IDFB15E					
	213	IDFB55E					
	214	IDFB75E					


Dust-protecting Filter Set/Dimensions





(IDF-FL209)

(IDF-FL203 to 208, 213, 214)



Dimension	s		Uni	t: inch [mm]
Part no.	Applicable dryer	Α	В	Weight Ib [g]
IDF-FL209	IDFB3E	8.7 [220]	9.4 [240]	0.08 [35]
IDF-FL203	IDFB4E	14.8	7.7	0.12
IDF-F L203	IDFB6E	[375]	[195]	[55]
IDF-FL204	IDFB8E	13.3 [340]	10.4	0.15 [70]
IDF-FL205	IDFB11E	14.8 [375]	[265]	0.17 [75]
IDF-FL206	IDFB15E	[17.3] 440	[14.5] 370	[0.26] 120
IDF-FL213	IDFB55E	28.3 [720]	15.7 [400]	0.39 [175]
IDF-FL214	IDFB75E	24 [610]	22 [560]	0.42 [190]

IDFB E Series Auto Drain Replacement Parts: Previous and New Model Product Nos.

As the auto drain part number differs depending on the serial number on the dryer specification label, be sure to confirm before ordering. There is no mounting interchangeability between the previous and new auto drains.

Auto drain (Bowl assembly)





Metal bowl guard

Transparent bowl guard (Polycarbonate)

New

Thread type: NPT

Dryer model	Dryer model Auto drain (B		Manufacturing date	SERIAL No.
IDFB3E/4E-11N	Previous	AD38N-Z	Manufactured in February 2019 and before	XP and before
IDFD3E/4E-IIN	New	AD38N-Z-D*1	Manufactured in March 2019 and after	XQ and after
IDFB6E/8E/11E/	Previous	AD48N-Z	Manufactured in February 2019 and before	XP and before
15E1/22E/37E-□N	New	AD48N-Z-D*1	Manufactured in March 2019 and after	XQ and after
IDFB55E/75E-	Previous	AD48N-Z	Manufactured in May 2019 and before	XS and before
	New	AD48N-Z-D*1	Manufactured in June 2019 and after	XT and after

Thread type: RC, R

Dryer model	Auto drain (Bowl assembly) part no.		Manufacturing date	SERIAL No.
IDFB3E/4E-11	Previous	AD38	Manufactured in February 2019 and before	XP and before
10-032/42-11	New	AD38-D*1	Manufactured in March 2019 and after	XQ and after
IDFB6E/8E/11E/	Previous	AD48	Manufactured in February 2019 and before	XP and before
15E1/22E/37E-	New	AD48-D*1	Manufactured in March 2019 and after	XQ and after
IDEB55E/75E-	Previous	AD48	Manufactured in May 2019 and before	XS and before
	New	AD48-D*1	Manufactured in June 2019 and after	XT and after

*1 The following models have mounting interchangeability: AD37-A and AD37-D, AD38-A and AD38-D, and AD48-A and AD48-D

In addition, note that the AD37-A, AD38-A, and AD48-A will no longer be able to be ordered after April 2025.

Option: K Moderate pressure specification (Auto drain bowl type: Metal bowl with level gauge)



Thread type: NPT

Dryer model	Auto drain (Bowl assembly) part no.		Manufacturing date	SERIAL No.	
IDFB6E/8E/11E/	Previous	IDF-S0201*2	Manufactured in February 2019 and before	XP and before	
15E-11N-K	New	IDF-S1927*3	Manufactured in March 2019 and after	XQ and after	
 *2 Assembly of auto drain: AD48N-8Z-X2110, One-touch fitting: KQ2H11-35AS, and insulator *3 Assembly of auto drain: AD48N-8Z-A-X2112, One-touch fitting: KQ2H11-35AS, and insulator 					
IDFB22E/37E-DN-K	Previous	AD48N-8Z-X2110*4	Manufactured in February 2019 and before	XP and before	
	New	AD48N-8Z-A-X2112*4	Manufactured in March 2019 and after	XQ and after	

*4 One-touch fitting: KQ2H11-35AS is not included.

Thread type: Rc, R

Dryer model Auto drain (Bowl assembly) part no.		Manufacturing date	SERIAL No.		
IDFB6E/8E/11E/	Previous	IDF-S0086*2	Manufactured in February 2019 and before	XP and before	
15E-11-K	New	IDF-S1926*3	Manufactured in March 2019 and after	XQ and after	
*2 Assembly of auto drain: AD48-8-A-X2110, One-touch fitting: KQ2H10-02AS, and insulator *3 Assembly of auto drain: AD48-8-A-X2112, One-touch fitting: KQ2H10-02AS, and insulator					
IDFB22E/37E-D-K	Previous	AD48-8-X2110*4	Manufactured in February 2019 and before	XP and before	
	New	AD48-8-A-X2112*4	Manufactured in March 2019 and after	XQ and after	

*4 One-touch fitting: KQ2H10-02AS




Manufacturing date

method

Serial number confirmation

Specification Label



Manufacturing 4

S

Manufacturing

	year
ymbol	Year
Α	1996
в	1997
:	:
w	2018
Х	2019
Y	2020
:	:

monui		
Symbol	Month	
0	1	
Ρ	2	
Q	3	
R	4	
S	5	
Т	6	
U	7	
٧	8	
w	9	
Х	10	
У	11	
y Z	12	





IDFB E Series Specific Product Precautions 1

Be sure to read this before handling the products. For safety instructions and air preparation equipment precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website: https://www.smcworld.com

Installation

A Caution

- Avoid locations where the air dryer will be in direct contact with wind and rain. (Avoid locations where relative humidity is greater than 85%.)
- Avoid exposure to direct sunlight.
- Avoid locations that contain much dust, corrosive gases, or flammable gases. Failure due to corrosion is not covered under warranty.
- Avoid locations of poor ventilation and high temperature.
- Allow ample space around the air dryer.
- Avoid locations where a dryer could draw in high temperature air that is discharged from an air compressor or other dryer.
- Avoid locations subjected to vibration.
- · Avoid possible locations where the drain can freeze.
- Use the air dryer with an ambient temperature lower than 104°F (40°C).
- Avoid installation on machines for transporting, such as trucks, ships, etc.
- Avoid locations which experience sudden pressure/flow rate changes.
- When installing in locations where the dripping of condensation is a problem

Depending on the operating conditions, the product and its downstream pipes could drip water due to condensation formed by supercooling.

If this is a problem, install a drain receiver below this product or the condensation points and empty it regularly.

Alternatively, wind additional insulation around the condensation points.

Drain Tube

A Caution

- A polyurethane tube is attached as a drain tube for the IDFB3E to 75E. Use this tube to discharge drainage.
- Do not use the drain tube in an upward direction. Do not bend or crush the drain tube. (The auto drain will not be activated and water will try to escape via the air outlet.)

If it is necessary that the tube goes upwards, make sure it only goes as far as the position of the auto drain.

• The drain tube comes with a tube fitting. Pipe a 10 mm O.D. tube with a length of 5 m or less.

Power Supply

A Caution


- · Connect the power supply to the terminal block.
- Install a suitable circuit breaker applicable for the specific model.
 The voltage fluctuation should be maintained within ±10% of the rated voltage.
- Note) Select a circuit breaker with a sensitivity current 30 mA. As regards rated current, refer to "Applicable circuit breaker capacity" on pages 161 and 165.

Air Piping

▲ Caution

- Be careful to avoid an error in connecting the air piping at the compressed air inlet (IN) and outlet (OUT).
- · Install by-pass piping since it is needed for maintenance.





IDFB4E to 15E


Compressed air inlet Compressed air outlet







Compressed air inlet



Compressed air outlet

- When tightening piping at the air inlet/outlet tube, the hexagonal parts of the port on the air dryer side or piping should be held firmly with a spanner or adjustable angle wrench.
- Variations in operating conditions may cause condensation to form at the surface of the outlet piping. Apply thermal insulation around the piping to prevent condensation from forming.
- Vibration resulting from the compressor should not be transmitted through air piping to the air dryer.
- Do not allow the weight of the piping to lie directly on the air dryer.
- If a metallic flexible tubing is used for the inlet/outlet air piping abnormal noise might be generated in the piping. In that case, please change it to the rigid tubing.



IDFB E Series Specific Product Precautions 2

Be sure to read this before handling the products. For safety instructions and air preparation equipment precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website: https://www.smcworld.com

Protection Circuit

A Caution

When the air dryer is operated under the following stated conditions, a protection circuit is activated, the light turns off and operation stops.

- When the compressed air temperature is too high.
- When the compressed air flow rate is too high.
- When the ambient temperature is too high. (104°F (40°C) or higher)
- When the fluctuation of the power supply is beyond the rated voltage $\pm 10\%$.
- When the dryer is drawing in high temperature air that is discharged from an air compressor or other dryer.
- . The ventilation port is obstructed by a wall or clogged with dust.

Compressor Air Delivery

A Caution

Use the air compressor with an air delivery of 3.5 SCFM (6 $m^{3} / h)$ or larger for the IDFB3E to 75E series.

Since the auto drain of the IDFB3E to 75E series is designed in such a way that the valve remains open unless the air pressure rises to 22 psi (0.15 MPa) or higher, air will blow out from the drain discharge port when the air compressor starts up until the pressure increases. Therefore, if the air compressor has a small air delivery, the pressure may not be sufficient.

Auto Drain

▲ Caution

The auto drain may not function properly, depending on the quality of the compressed air. Check the operation once a day.

Cleaning of Ventilation Area

A Caution

Remove dust from the ventilation area once a month using a vacuum cleaner or an air blow nozzle.

Delay for Restarting

A Caution

- Allow at least three minutes before restarting the dryer. If the air dryer is restarted within three minutes after being stopped, the protection circuit will be activated, operating light will turn off and the dryer will not be activated.
- The residual drainage in the air dryer may splash over the outlet when the operation is re-started, so it is recommended to install a filter on the outlet of the air dryer.

Modifying the Standard Specifications

Do not modify the standard product using any of the optional specifications once the product has been supplied to a customer. Check the specifications carefully before selecting an air dryer. In addition, do not disassemble or modify the product. Products which have been disassembled and/or modified cannot be guaranteed.

Refrigerant with GWP reference

	Global Warming Potential (GWP)						
Refrigerant	Regulation (EU)	Fluorocarbon Emissions Control Act (Japan)					
Heingerani	2024/573,	GWP value labeled on	GWP value to be used for reporting				
	AIM Act 40 CFR Part 84	products	the calculated amount of leakage				
R134a	1,430	1,430	1,300				
R404A	3,922	3,920	3,940				
R407C	1,774	1,770	1,620				
R410A	2,088	2,090	1,920				
R448A	1,386	1,390	1,270				
R454C	146	145	146				

Note 1) This product is hermetically sealed and contains fluorinated greenhouse gases (HFC). When this product is sold on the market in the EU after January 1, 2017, it needs to be compliant with the quota system of the F-Gas Regulation in the EU.

Note 2) See specification table for refrigerant used in the product.

